

Datasheet Version 1.0








1.0	Overview	03	13.0	Bluetooth	14
2.0	Features	03	13.1 13.2	Supported features Specification	14 14
3.0	Specifications	04	13.2.1 13.2.2	Receiver – Basic Data Rate Receiver – Enhanced Data Rate	14 15
3.1	CPU	04	13.2.3	Receiver – Bluetooth LE	16
3.2	Memory	04	13.2.4	Transmitter – Basic Data Rate	17
3.3	WiFi	04	13.2.5	Transmitter – Enhanced Data Rate	18
3.4	Bluetooth	04	13.2.6	Transmitter – Bluetooth LE	19
3.5	LTE CAT-M1/NB-IoT	04	14.0	LTE CAT-M1/NB-IoT	20
3.6	RTC	04	7.4.7	0	0.0
3.7	Security	04	14.1	Supported features	20
3.8	Hash / encryption	04	14.2	Specifications	20
4.0	Block Diagram	04	14.2.1	''	20
			14.3	SIM Card requirements	20
5.0	Pinout	05	14.4	Certified carriers	20
<i>c</i> 0	Die Dataille	0.0	15.0	Electrical Characteristics	21
6.0	Pin Details	06	15.1	Absolute maximum ratings	21
6.1	Remapping Pins	08	15.2	Input/Output characteristics	21
7.0	ESP32 Peripherals	09	16.0	Minimum Recommended Circuit	22
7.1	RTC	09	17.0	Mechanical Specifications	23
8.0	Programming the device	10			
8.1	UART	10	18.0	Recommended Land Patterns	23
8.2	Wi-Fi	10	10.0	Design Considerations	2.4
8.2.1	Telnet	10	19.0	Design Considerations	24
8.2.2	FTP	10	19.1	Antenna Impedance	24
9.0	Boot modes	10	19.2	Deep sleep power	24
	Door modes		19.3	Reference layout	25
9.1	Bootloader mode	10	20.0	Soldering Profile	26
9.2	Safe boot	10	20.0	colucining rounc	
10.0	Power	11	21.0	Ordering Information	27
10.1	Current consumption by power	11	22.0	Packaging	27
	modes/features running at 3.7V	11	22.1	Reel	27
11.0	Memory Map	12	22.1	Tape	27
11.1	Flash	12	22.2	Box	27
11.2	RAM	12			
11.3	ROM and eFuses	12	23.0	Certification	28
12.0	WiFi	13	24.0	Regulator Information	28
12.1	Supported features	13	24.1	EU Regulatory Conformance	28
12.2	Specifications	13	24.2	Federal Communication Commission	
				Interference Statement	28
			24.2.1	RF Warning Statement	28
			24.2.2	OEM integrator conditions	28
			24.2.3	End Product Labelling	29
			24.2.4	Manual Information to the End User	29
			25.0	Revision History	29







Size

40mm x 16mm x 2.7mm

## 1.0 Overview

With WiFi, BLE and cellular LTE-CAT M1/NB1, the G01 OEM Module is the latest Pycom triple-bearer MicroPython enabled micro controller on the market today – the perfect enterprise grade IoT platform for your connected things. Create and connect your things everywhere, fast.

## 2.0 Features

- Powerful CPU, BLE and state of the art WiFi radio. 1KM Wifi Range
- MicroPython enabled
- Can be directly surface mount inside your product like a regular component
- Ultra-low power usage: a fraction compared to other connected micro controllers





# 3.0 Specifications

#### 3.1 CPU

- Xtensa® dual-core 32-bit LX6 microprocessor(s), up to 600 DMIPS
- Hardware floating point acceleration
- Python multi-threading
- An extra ULP-coprocessor that can monitor GPIOs, the ADC channels and control most of the internal peripherals during deep-sleep mode while only consuming 25uA.

#### 3.2 Memory

- RAM: 520KB + 4MB
- External flash: 8MB

#### 3.3 WiFi

- 802.11b/g/n 16mbps

#### 3.4 Bluetooth

- Low energy and classic

#### 3.5 LTE CAT-M1/NB-IoT

- One single chip for both CAT M1 and NB1
- 3GPP release 13 LTE Advanced Pro
- Supports narrowband LTE UE categories M1/NB1
- Integrated baseband, RF, RAM memory and power management
- Reduced TX power class option
- Peak power estimations:
  - TX current = 420mA peak @1.5Watt RX current = 330mA peak @1.2Watt
- Extended DRX (eDRX) and PSM features for long sleep duration use cases

#### 3.6 RTC

- Running at 150kHz

#### 3.7 Security

- SSL/TLS support
- WPA Enterprise security

#### 3.8 Hash / encryption

- SHA
- MD5
- DES
- AES

## 4.0 Block Diagram




Figure 1 – System block diagram





05

# 5.0 Pinout




Figure 2 – Module pinout diagram

Note: The ESP32 supports remapping its peripherals to alternative pins. See below for a detailed list.





# 6.0 Pin Details

Table 1 – Module pinout

Module Pin	ESP32 GPI0	Pin Name	Default Function	ADC	PWM	RTC†	Notes
1	_	-	Ground				
2	_	_	Ground				
3	_	_	Ground				
4	-	_	USIM Clock				
5	-	_	USIM I/O				
6	-	-	Ground				
7	-	_	Ground				
8	-	_	Ground				
9	-	_	Reset				Active Low
10	3	P0	RX0 (Programming)		•		Used by the bootloader and to program the module
11	1	P1	TX0 (Programming)		•		Used by the bootloader and to program the module
12	0	P2		2*	•	•	If tied to GND during boot the device will enter bootloader mode
13	4	Р3	TX1	2*	•	•	
14	15	P4	RX1	2*	•	•	JTAG TDO, SD card CMD
15	5	_	Sequans modem RX		•		Not recommended for external use
16	27	_	Sequans modem Interrupt	2*	•	•	Not recommended for external use
17	19	_	Sequans modem CTS		•		Not recommended for external use
18	2	P8		2*	•	•	SD card DAT0
19	12	P9	SDA	2*	•	•	JTAG TDI





# 6.0 Pin Details

Table 1 – Module pinout

Module Pin	ESP32 GPI0	Pin Name	Default Function	ADC	PWM	RTC†	Notes
20	13	P10	SCL (I2C) / CLK (SPI)	2*	•	•	JTAG TCK
21	22	P11	MOSI		•		
22	21	P12			•		If tied to 3.3V during boot the device enters safe boot mode, JTAG MISO
23	_	_	Ground				
24	_	_	Ground				
25	_	-	WiFi/BT antenna				50 Ohm impedance required
26	_	-	Ground				
27	_	_	Ground				
28	_	-	Ground				
29	36	P13		1		•	Input only
30	37	P14		1		•	Input only
31	38	P15		1		•	Input only
32	39	P16		1		•	Input only
33	35	P17		1		•	Input only
34	34	P18		1		•	Input only
35	32	P19		1	•	•	
36	33	P20		1	•	•	Connected to the on-board RGB LED
37	26	P21		2*	•	•	DAC
38	25	P22		2*	•	•	DAC
39	14	P23		2*	•	•	JTAG TMS, SD card SCLK





# 6.0 Pin Details

Table 1 – Module pinout

Module Pin	ESP32 GPI0	Pin Name	Default Function	ADC	PWM	RTC†	Notes
40	-	_	3.3V input				This supply should be able to source 650mA
41	_	_	Ground				
42	_	_	1.8V Output				Only when the device is active, during deep sleep this drops to 0V
43	-	-	Ground				
44	_	_	Ground				
49	-	_	3.2-5.5V input				Powers the Sequans cellular modem
50	-	_	Ground				
51	-	_	LTE CAT-M1/NB- IoT antenna				699–960 and 1710–2170Mhz depending on local carrier bands, 50 Ohm impedance required
52	-	_	Ground				
_	23	_	Sequans modem TX				
_	18	_	Sequans modem RTS				

<sup>†</sup> The pins on the RTC power domain can be used during deep sleep, specifically GPIO pins will maintain their state while in deep sleep.

# 6.1 Remapping Pins

The ESP32 features comprehensive pin remapping functionality. This allows peripherals to be mapped onto almost any available GPIO pins. The above table merely shows the default assignments. For example, the default mapping has the SPI and I2C clocks overlapping, meaning both cannot be used simultaneously without

remapping one to a different pin. For a detailed guide of what peripheral can be assigned to what pins please read "Appendix A – ESP32 Pin Lists" of the ESP32 datasheet.

<sup>\*</sup> ADC2 is currently not supported in the micropython firmware





# 7.0 ESP32 Peripherals


Table 2 – Peripherals

Peripheral	Count	Pins
UART	3	Remappable to any GPIO.  Note: P13–18 can only be mapped to RX or CTS since they are input only.
12C	2	Remappable to any GPIO except P13–18 since they are input only and I2C is bi-directional.
SPI	3	Remappable to any GPIO.  Note: P13–18 can only be mapped to MISO since they are input only.
CAN*	1	Remappable to any GPIO.  Note: P13–18 can only be mapped to RX since they are input only.
JTAG	1	TDO = P4, TDI = P9, TCK = P10, TMS = P24
PWM	1	All GPIO except P13–18 which are input only
ADC	18	Fixed mapping, see Table 1, Only ADC 1 is supported in our micropython firmware.
DAC	2	Only available on P21 and P22
SD Requires an external Co	1 AN hus transceiver	DATO = P8, SCLK = P23, CMD = P4 we recommend the SN65HVD230 from Texas Instruments.

For a more detailed description of the ESP32 peripherals along with peripherals not currently supported by our firmware, please check the ESP32 datasheet.

# 7.1 RTC

Our modules by default all use the internal RC oscillator at 150kHz for the RTC. If you require better accuracy/ stability you can connect a 32.768 kHz crystal (or TCXO) externally on pins P19 and P20 (or P19 for a TXCO)






Figure 3 – External RTC crystal circuits





## 8.0 Programming the device

#### 8.1 UART

By default, the modules run an interactive python REPL on UART0 which is connected to P0 (RX) and P1 (TX) running at 115200 baud. Code can be run via this interactive REPL or you can use our PyMakr plugin for Atom or Visual Studio Code to upload code to the board.

#### 8.2 Wi-Fi

By default, the G01 also acts as a Wi–Fi access point SSID: gpy–wlan–XXXX
Password: www.pycom.io
Once connected to the G01's Wi–Fi network you can access it in two ways.

#### 9.0 Boot modes

#### 9.1 Bootloader mode

In order to update the firmware of the G01 device, it needs to be placed into bootloader mode. In order to do this, P2 needs to be connected to ground when the device reboots. Once in bootloader mode you can use the Pycom firmware update tool to update to the latest official firmware. If you are developing your own firmware based on our open—source firmware, a flashing script is provided with the source code.

#### Table 3 - Boot modes

#### 0-3 Seconds

Current firmware without running boot.py or main.py

#### 8.2.1 Telnet

Running on port 23 is a telnet server. This acts in a very similar way to the UART. It presents you with an interactive REPL and can also be used to upload code via PyMakr.

#### 8.2.2 FTP

The G01 also runs a FTP server that allows you to copy files to and from the device, include an SD card if one is connected. To connect to this FTP server, you need to use plain FTP (un-encrypted) with the following credentials: User: micro

Password: python

## 9.2 Safe boot

The micropython firmware features a safe boot feature that skips the boot.py and main.py scripts and goes straight to the REPL. This is useful if the device is programmed with code that causes the device to crash or become inaccessible. To access this mode, you need to connect P12 to 3.3V and reset the device. Upon entering safe boot mode, the on–board LED will begin to blink orange. Depending on the duration the pin is held at 3.3V, a different firmware will be run.

#### 3-6 Seconds

Previous firmware if the firmware was uploaded via OTA (without running boot.py and main.py)





# 10.0 Power

The module requires a regulated 3V3 power supply (for WiFi, Bluetooth and the core processor), and a non-regulated 3.2 to 5.5V supply for the LTE sub-system. The 1V8 pin is only an output which is enabled whenever the module is in active mode. During deepsleep the 1V8 signal goes low. Do not supply power to the 1V8 pin, and never use this pin as a power supply, only as a control signal.

## 10.1 Current consumption by power modes/features running at 3.7V

Table 4 – Power consumption by feature

Mode	Min	Avg.	Max	Units
Idle (no radios)	-	37	-	mA
LTE Transmit	-	173	285	mA
LTE Attached	-	75	-	mA
WiFi AP	-	117	-	mA
WiFi client	-	130	_	mA
Bluetooth	-	113	_	mA
Deep sleep	-	13.5	-	mA





# 11.0 Memory Map

## 11.1 Flash

Table 5 – Flash memory map

Name	Description	Start address	Size
NVS	Non-volatile RAM area. Used by the NVS API	0x9000	0x7000
Firmware Slot 0	First firmware slot. Factory firmware is flashed here	0x10000	0x180000
OTA info	Information about the current active firmware	0x190000	0x1000
Firmware Slot 1	Second firmware slot	0x1A0000	0x180000
File system	504KB file system on devices with 4MB flash	0x380000	0x7F000
Config	Config area for LoRa, Sigfox and LTE	0x3FF000	0x1000
File system (2)	4MB file system on devices with 8MB flash	0x400000	0x400000

## 11.2 RAM

Table 6 – RAM memory map

Name	Description	Size
On-chip SRAM	Internal RAM memory used by the 2 xtensa CPUs	520KB
Fast RTC RAM	Fast RAM area accessible by the xtensa cores during boot and sleep modes	8KB
Slow RTC RAM	Slow RAM area accessible by the Ultra-Low Power Coprocessor during deep sleep	8KB
External pSRAM	External QSPI RAM memory clocked @ 40MHz	4MB

## 11.3 ROM and eFuses

Table 7 – Miscellaneous memory

Name	Description	Size
On-chip ROM	Contains core functions and boot code.	448KB
eFuse	256 bits are used for the system (MAC address and chip configuration) and the remaining 768 bits are reserved for customer applications, including Flash–Encryption and Chip–ID	1kbit





# 12.0 WiFi

#### 12.1 Supported features

- 802.11 b/g/n/e/i
- 802.11 n (2.4 GHz), up to 150 Mbps
- 802.11 e: QoS for wireless multimedia technology
- WMM-PS, UAPSD
- A-MPDU and A-MSDU aggregation
- Block ACK
- Fragmentation and defragmentation

- Automatic Beacon monitoring/scanning
- 802.11 i security features: pre-authentication and TSN
- Wi-Fi Protected Access (WPA/WPA2/WPA2-Enterprise/Wi-Fi Protected Setup (WPS)
- Infrastructure BSS Station mode/SoftAP mode
- Wi-Fi Direct (P2P), P2P Discovery, P2P Group Owner mode and P2P Power Management

# 12.2 Specifications

Table 8 – WiFi specifications

2412	-	2484	MHz
13	14	15	dBm
19.5	20	20.5	dBm
Sens	itivity		
_	-	98	dBm
-	-	91	dBm
-	-	93	dBm
-	-	75	dBm
-	-	93	dBm
-	-	73	dBm
-	-	90	dBm
-	-	70	dBm
-	-	89	dBm
Adjacent cha	nnel rejection		
_	37	-	dB
_	21	-	dB
_	37	-	dB
-	20	-	dB
	13 19.5 Sens Adjacent cha	13 14  19.5 20  Sensitivity	13 14 15  19.5 20 20.5  Sensitivity  98  91  93  75  93  73  90  70  - 89  Adjacent channel rejection  - 37 1 - 21 - 1 - 1 - 1 - 1 - 1 - 1 - 1





## 13.0 Bluetooth

#### 13.1 Supported features

- Compliant with Bluetooth v4.2 BR/EDR and BLE specification
- Class-1, class-2 and class-3 transmitter without external power amplifier
- Enhanced power control
- +12 dBm transmitting power
- NZIF receiver with -97 dBm sensitivity
- Adaptive Frequency Hopping (AFH)
- Standard HCI based on SDIO/SPI/UART
- High-speed UART HCI, up to 4 Mbps
- BT 4.2 controller and host stack

- Service Discover Protocol (SDP)
- General Access Profile (GAP)
- Security Manage Protocol (SMP)
- ATT/GATT
- HID
- All GATT-based profile supported
- SPP-like GATT-based profile
- BLE Beacon
- A2DP/AVRCP/SPP, HSP/HFP, RFCOMM
- CVSD and SBC for audio codec
- Bluetooth Piconet and Scatternet

## 13.2 Specification

## 13.2.1 Receiver - Basic Data Rate

Table 9 - Receiver (basic data rate) specifications

Parameter		Min	Тур.	Max	Unit
Sensitivity @0.1% BER		-	-94	-	dBm
Maximum received signal @0.1% BER		0	_	-	dBm
Co-channel C/I		-	+7	-	dB
	F = F0 + 1 MHz	-	_	-6	dB
	F = F0 - 1 MHz	-	_	-6	dB
	F = F0 + 2 MHz	_	_	-25	dB
Adjacent channel selectivity C/I	F = F0 - 2 MHz	-	_	-33	dB
	F = F0 + 3 MHz	-	-	-25	dB
	F = F0 - 3 MHz	_	-	-45	dB
	30Mhz ~ 2000MHz	-10	_	_	dBm
	2000MHz ~ 2400MHz	-27	-	-	dBm
Out-of-band blocking performance	2500MHz ~ 3000MHz	-27	_	-	dBm
	3000MHz ~ 12.5GHz	-10	_	-	dBm
Intermodulation		-36	-	-	dBm





13.2.2 Receiver - Enhanced Data Rate

Table 10 – Receiver (basic data rate) specifications

Parameter		Min	Тур.	Max	Unit			
$\pi/4$ DQPSK								
Sensitivity @0.1% BER		-	-90	-	dBm			
Maximum received signal @0.1% BER		-	0	-	dBm			
Co-channel C/I		-	11	-	dB			
	F = F0 + 1 MHz	-	-7	-	dB			
	F = F0 - 1 MHz	-	-7	-	dB			
Adiacant abanyal salaatiyity 0/1	F = F0 + 2 MHz	-	-25	-	dB			
Adjacent channel selectivity C/I	F = F0 - 2 MHz	-	-35	-	dB			
	F = F0 + 3 MHz	-	-25	-	dB			
	F = F0 - 3 MHz	-	-45	-	dB			
	8DF	PSK						
Sensitivity @0.1% BER		-	-84	-	dBm			
Maximum received signal @0.1% BER		-	-5	-	dBm			
C/I c-channel		-	18	_	dB			
	F = F0 + 1 MHz	-	2	_	dB			
	F = F0 - 1 MHz	_	2	-	dB			
Allowed themselved at 2000	F = F0 + 2 MHz	-	-25	-	dB			
Adjacent channel selectivity C/I	F = F0 - 2 MHz	-	-25	-	dB			
	F = F0 + 3 MHz	_	-25	-	dB			
	F = F0 - 3 MHz	_	-38	-	dB			





13.2.3 Receiver - Bluetooth LE

Table 11 - Receiver (BLE) specifications

Parameter		Min	Тур.	Max	Unit
Sensitivity @30.8% PER		-	-97	-	dBm
Maximum received signal @30.8% PER		0	_	-	dBm
Co-channel C/I		_	+10	_	dB
	F = F0 + 1MHz	_	-5	-	dB
	F = F0 - 1MHz	_	-5	-	dB
	F = F0 + 2MHz	_	-25	-	dB
Adjacent channel selectivity C/I	F = F0 - 2MHz	_	-35	_	dB
	F = F0 + 3MHz	_	-35	_	dB
	F = F0 - 3MHz	_	-45	_	dB
Out—of—band blocking performance	30MHz ~ 2000MHz	-10	-	-	dB
	2000MHz ~ 2400MHz	-27	-	-	dBm
	2500MHz ~ 3000MHz	-27	-	-	dBm
	3000MHz ~ 12.5GHZ	-10	-	-	dBm
Intermodulation		-36	-	_	dBm





# 13.2.4 Transmitter - Basic Data Rate

Table 12 – Transmitter (basic data rate) specifications

Parameter		Min	Тур.	Max	Unit
RF transmit power		_	0	-	dBm
Gain control step		-	±3	-	dBm
RF power control range		-12	-	+12	dBm
+20 dB bandwidth		_	0.9	-	MHz
	F = F0 + 1 MHz	_	-24	-	dBm
	F = F0 - 1 MHz	-	-16.1	-	dBm
	F = F0 + 2 MHz	-	-40.8	-	dBm
A dia a and also am al dua manais manuan	F = F0 - 2 MHz	_	-35.6	-	dBm
Adjacent channel transmit power	F = F0 + 3 MHz	-	-45.7	-	dBm
	F = F0 - 3 MHz	_	-40.2	-	dBm
	F = F0 + >3 MHz	_	45.6	-	dBm
	F = F0 - >3 MHz	_	44.6	-	dBm
$\Delta f1_{avg}$		-	-	155	KHz
$\Delta f2_{\text{max}}$		133.7			KHz
$\Delta f 2_{avg}/\Delta f 1_{avg}$		_	0.92	-	-
ICFT		_	-7	_	KHz
Drift rate		-	0.7	_	KHz/50μs
Drift (1 slot packet)		-	6	-	KHz
Drift (5 slot packet)		_	6	-	KHz





# 13.2.5 Transmitter - Enhanced Data Rate

Table 13 – Transmitter (enhanced data rate) specifications

Parameter		Min	Тур.	Max	Unit
RF transmit power		_	0	-	dBm
Gain control step		_	±3	-	dBm
RF power control range		-12	_	+12	dBm
π/4 DQPSK max w0		_	-0.72	_	KHz
π/4 DQPSK max wi		_	-6	_	KHz
π/4 DQPSK max  wi + w0		_	-7.42	_	KHz
8DPSK max w0		-	0.7	_	KHz
8DPSK max wi		_	-9.6	_	KHz
8DPSK max  wi + w0			-10		KHz
	RMS DEVM	_	4.28	_	%
π/4 DQPSK modulation accuracy	99% DEVM	_	-	30	%
	Peak DEVM	_	13.3	_	%
	RMS DEVM	_	5.8	-	%
8 DPSK modulation accuracy	99% DEVM	_		20	%
	Peak DEVM	_	14	_	%
	F = F0 + 1MHz	_	-34	_	dBm
	F = F0 - 1MHz	_	-40.2	-	dBm
	F = F0 + 2MHz	_	-34	-	dBm
F = F0 + 3MH	F = F0 - 2MHz	_	-36	_	dBm
	F = F0 + 3MHz	-	-38	-	dBm
	F = F0 - 3MHz	_	-40.3	-	dBm
F = F0 ± >3M		_	-	-41.5	dBm
EDR differential phase coding		-	100	-	%





# 13.2.6 Transmitter – Bluetooth LE

Table 14 – Transmitter (BLE) specifications

Parameter		Min	Тур.	Max	Unit
RF transmit power		-	0	-	dBm
Gain control step		-	±3	-	dBm
RF power control range		-12	-	+12	dBm
	F = F0 + 1MHz	-	-14.6	-	dBm
	F = F0 - 1MHz	-	-12.7	-	dBm
	F = F0 + 2MHz	-	-44.3	-	dBm
Adianant alamat tuan anti-	F = F0 - 2MHz	-	-38.7	-	dBm
Adjacent channel transmit power	F = F0 + 3MHz	-	-49.2	-	dBm
	F = F0 - 3MHz	-	-44.7	-	dBm
	F = F0 + >3MHz	-	-50	-	dBm
	F = F0 - >3MHz	_	-50	-	dBm
$\Delta f 1_{avg}$		-	-	265	KHz
$\Delta f 2_{\text{max}}$		247	-	-	KHz
$\Delta f 2_{avg}/\Delta f 1_{avg}$		-	-0.92	-	_
ICFT		-	-10	_	KHz
Drift rate		_	0.7	_	KHz/50µs
Drift		_	2	_	KHz





# 14.0 LTE CAT-M1/NB-IoT

#### 14.1 Supported features

- 12 bands supported from 699Mhz to 2690Mhz (Total worldwide support)
- 3GPP release 13 LTE Advanced Pro
- Supports narrowband LTE UE categories M1/NB1
- Integrated baseband, RF, RAM memory and power management
- Reduced TX power class option
- Extended DRX (eDRX) and PSM features for long sleep duration use cases

Table 15 – LTE modem performance

Parameter		Min	Тур.	Max	Unit
	LTE Cat M1 in 1.4 Mhz, HD-FDD - DL	_	300	_	kbps
LTE Cat M1 in 1.4 Mhz, HD-FDD - UP	LTE Cat M1 in 1.4 Mhz, HD-FDD - UP	_	375	_	kbps
Data rate	LTE Cat NB1 in 200 kHz, HD-FDD - DL	_	40	_	kbps
	LTE Cat NB1 in 200 kHz, HD-FDD - UL	_	55	_	kbps

# 14.2.1 Supported LTE bands

Table 16 – Supported LTE bands

Bands	TX Frequencies	RX Frequencies
Low Bands 5, 8, 12, 13, 18, 19, 20, 28	699 to 915 MHz	729 to 960 MHz
Mid Bands 1, 2, 3, 4	1710 to 1980 MHz	1805 to 2170 MHz

# 14.3 SIM Card requirements

Table 17 – SIM card specificiations

Parameter	Min	Тур.	Max	Unit
Form factor	-	Nano-SIM	_	_
Variant	-	USIM	_	_
Supply Voltage	-	1.8	-	٧

# 14.4 Certified carriers

Table 18 – Certified carriers

Carrier	Country	Network
Verizon US	United States	LTE CAT-M1





# 15.0 Electrical Characteristics

# 15.1 Absolute maximum ratings

Table 19 – Absolute maximum ratings

Parameter	Symbol	Min	Тур.	Max	Unit
Supply Input Voltage	$V_{\text{IN}}$	3.5	-	5.5	V
Supply Output Current	I <sub>оит</sub>	-	_	1.2	А
Supply Output Voltage	$V_{3V3}$	_	3.3	_	V
Storage Temperature	T <sub>STR</sub>	-	_	_	°C
Operating Temperature	$T_OPR$	-40	_	85	°C
Moisture Sensitivity Level	MSL	-	1	-	-

# 15.2 Input/Output characteristics

Table 20 – Input/Output characteristics

Symbol	Min	Тур.	Max	Unit
$V_{IL}$	-0.3	-	0.25×V <sub>3V3</sub>	V
$V_{IH}$	0.75×V <sub>3V3</sub>	-	V <sub>3V3</sub> +0.3	V
Isink	-	6	12	mA
I <sub>IL</sub>	-	-	50	nA
$C_pin$	-	-	2	pF
$V_{OL}$	0.1×V <sub>3V3</sub>	-	-	V
$V_{OH}$	0.8×V <sub>3V3</sub>	-	-	V
I <sub>SOURCE</sub>	_	6	12	mA
	V <sub>IL</sub> V <sub>IH</sub> ISINK I <sub>IL</sub> C <sub>pin</sub> V <sub>OL</sub>	V <sub>IL</sub> −0.3  V <sub>IH</sub> 0.75×V <sub>3V3</sub> I <sub>SINK</sub> −  I <sub>IL</sub> −  C <sub>pin</sub> −  V <sub>OL</sub> 0.1×V <sub>3V3</sub> V <sub>OH</sub> 0.8×V <sub>3V3</sub>	V <sub>IL</sub> -0.3       -         V <sub>IH</sub> 0.75×V <sub>3V3</sub> -         I <sub>SINK</sub> -       6         I <sub>IL</sub> -       -         C <sub>pin</sub> -       -         V <sub>OL</sub> 0.1×V <sub>3V3</sub> -         V <sub>OH</sub> 0.8×V <sub>3V3</sub> -	$\begin{array}{cccccccccccccccccccccccccccccccccccc$





# 16.0 Minimum Recommended Circuit




Figure 4 – Minimum required circuit





# 17.0 Mechanical Specifications




Figure 5 – Mechanical drawing (top down view)

## 18.0 Recommended Land Patterns




Figure 6 – Recommended land pattern





# 19.0 Design Considerations

#### 19.1 Antenna Impedance

Our OEM modules are intended to be used with a 50-ohm antenna. They are also required to be connected to the antenna by a 50-ohm grounded co-planar waveguide (as shown in the reference design below with the yellow lines) or a microstrip.






Figure 7 – 50-ohm impedance antenna connections

## 19.2 Deep sleep power

When selecting a voltage regulator for your application ensure that it has a low power mode, and that this is enabled when the device enters deep sleep. We also recommend cutting off power to all non-essential components such as LEDs, logic gates, sensors etc. when the device is in deep sleep. This can be done

using the circuit shown right:

This circuit uses the 1.8V output of the module to cut off supply to non–essential circuitry. The 1.8V output is only active when the module is running, when it goes to deep sleep it drops to 0V. The non–essential circuitry is then powered from the "ACTIVE\_POWER" bus




Figure 8 – Power switch for deep sleep mode





# 19.3 Reference layout

Below you will find the designs for our universal reference board that fits all of our OEM modules. The design files can be downloaded from our website.




Figure 9 – PCB layers for reference design – Units: mm





# 20.0 Soldering Profile




Figure 10 – Reflow soldering temperature profile

Table 21 – Soldering profile temperatures

Stage	Duration/Rate	Temperature
Ramp to soak	2°C/s	Ambient – 185°C
Soak	60s	185°C
Ramp to peak	1°C/s	240°C
Reflow	45s	>225°C
Cool down	2°C/s	

The above profile is based on Alpha CVP-390 solder paste, which has been successfully tested with our devices.





# 21.0 Ordering Information


Table 22 – Ordering information

Product EAN	Description
0700461341598	G01 – OEM version of GPy 1.0
0700461908845	Reel of 250 G01 OEM modules
0700461908968	Reel of 500 G01 OEM modules

# 22.0 Packaging

## 22.1 Reel


Figure 11 – Mechanical drawing of reel – Units: mm



Box


22.3

Figure 13 – Mechanical drawing of reel box – Units: mm



22.2 Tape

Figure 12 – Mechanical drawing of reel tape – Units: mm







#### 23.0 Certification

FCC 2AJMTG01R IC 22263-G01R

CE 0700

Copies of the certificates can be found on our website.

## 24.0 Regulator Information

#### 24.1 EU Regulatory Conformance

Hereby, Pycom Ltd declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC

#### 24.2 Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### 24.2.1 RF Warning Statement

To comply with FCC RF exposure compliance requirements, the antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

## 24.2.2 OEM integrator conditions

This device is intended only for OEM integrators under the following conditions:

- 1. The antenna must be installed such that 20 cm is maintained between the antenna and users, and
- 2. The transmitter module may not be co-located with any other transmitter or antenna.

As long as the two conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end–product for any additional compliance requirements required with this module installed. To ensure compliance with all non–transmitter functions the host manufacturer is responsible for ensuring compliance with the module(s) installed and fully operational. For example, if a host was previously authorized as an unintentional radiator under the Declaration of Conformity procedure without a transmitter certified module and a module is added, the host manufacturer is responsible for ensuring that the after the module is installed and operational the host continues to be compliant with the Part 15B unintentional radiator requirements.

The module is limited to OEM installation ONLY. The module is limited to installation in mobile or fixed application. We hereby acknowledge our responsibility to provide guidance to the host manufacturer in the event that they require assistance for ensuring compliance with the Part 15 Subpart B requirements.





IMPORTANT NOTE: In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for reevaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

#### 24.2.3 End Product Labelling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labelled in a visible area with the following: "Contains FCC ID: 2AJMTG01R". The grantee's FCC ID can be used only when all FCC compliance requirements are met.

The following FCC part 15.19 statement has to also be available on the label:

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

#### 24.2.4 Manual Information to the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

In the user manual of the end product, the end user has to be informed that the equipment complies with FCC radio—frequency exposure guidelines set forth for an uncontrolled environment.

The end user has to also be informed that any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

The end user manual shall include all required regulatory information/warning as show in this manual.

The maximum operating ambient temperature of the equipment declared by the manufacturer is  $-40 \sim +85C$ 

Receiver category 3

## 25.0 Revision History

Table 23 - Document revision history

Version 1.0 Initial Release